

# BORMAX GUIDE

## FRAISE DE PRÉCISION POUR BOIS

### CODES ET DIMENSIONS

CODE	Ø fraise [mm]	Ø trou interne pour centrage [mm]	Ø tige [mm]	LT [mm]	LU [mm]	pcs.
<b>F1614020</b>	20	8	13	140	90	1
<b>F1614025</b>	25	8	13	140	90	1
<b>F1614030</b>	30	8	13	140	90	1
<b>F1614035</b>	35	8	13	145	95	1
<b>F1614040</b>	40	10	13	145	95	1
<b>F1614045</b>	45	10	13	150	100	1
<b>F1614050</b>	50	10	13	150	100	1
<b>F1614055</b>	55	10	13	150	100	1
<b>F1614060</b>	60	10	13	150	100	1
<b>F1614065</b>	65	10	13	155	105	1
<b>F1614070</b>	70	10	13	155	105	1
<b>F1614075</b>	75	10	13	155	105	1
<b>F1614080</b>	80	10	13	155	105	1
<b>F1614100</b>	100	10	16	160	110	1
<b>F1614110</b>	110	10	16	160	110	1
<b>F1614120</b>	120	10	16	160	110	1

Mèche de centrage et clé hexagonale fournis.



LT longueur totale

LU longueur utile



### FORET POUR PRÉ-PERÇAGE

CODE	Ø tige [mm]	pour fraises avec Ø [mm]	LT [mm]	LU [mm]	pcs.
<b>F1614208</b>	8	20 - 35	75	50	1
<b>F1614210</b>	10	40 - 120	75	50	1



### MÈCHE DE CENTRAGE

CODE	Ø [mm]	Ø tige [mm]	pour fraises avec Ø [mm]	pcs.
<b>F1619208</b>	3,15	8	20 - 35	1
<b>F1619210</b>	4,0	10	40 - 120	1



### GOUPILLE DE GUIDAGE

CODE	Ø [mm]	Ø tige [mm]	pour fraises avec Ø [mm]	LT [mm]	LU [mm]	pcs.
<b>F1619008</b>	8		20 - 35	75	50	1
<b>F1619110</b>	10		20 - 35	75	50	1
<b>F1619112</b>	12		20 - 35	75	50	1
<b>F1619114</b>	14	8	20 - 35	75	50	1
<b>F1619116</b>	16		20 - 35	75	50	1
<b>F1619118</b>	18		20 - 35	75	50	1
<b>F1619120</b>	20		20 - 35	75	50	1
<b>F1619012</b>	12		40 - 120	75	50	1
<b>F1619014</b>	14		40 - 120	75	50	1
<b>F1619016</b>	16	10	40 - 120	75	50	1
<b>F1619018</b>	18		40 - 120	75	50	1
<b>F1619020</b>	20		40 - 120	75	50	1



### BUTÉE DE PROFONDEUR

CODE	pour fraises avec Ø [mm]	Ø intérieur [mm]	pcs.
<b>F1619100</b>	40 - 90	95	1

