



GAP 3 GROOVE GEOMETRY




SYMMETRICAL GROOVING

Min. thickness	F	0.12 in
Min. recommended height GAP 3	H	0.32 in


GAP 3 INSTALLATION




First board: fix it with suitable screws, left visible or hidden thanks to specific accessories.




Insert the GAP3 fastener into the groove cut so that the clip's central tab adheres to the groove in the board.




Fix the screw in the central hole.



Position the next board by inserting it into the GAP3 fastener so that the two tabs adhere to the groove in the board.




Using the CRAB MINI clamp, tighten the two boards until the gap between them is 0.12 - 0.16 inch depending on aesthetic requirements (see product page 424).



Repeat the operations for the remaining boards.
Last board: repeat step 01.


GAP 4 GROOVE GEOMETRY




SYMMETRICAL GROOVING

Min. thickness	F	0.12 in
Min. recommended height GAP 4	H	0.28 in


GAP 4 INSTALLATION




First board: fix it with suitable screws, left visible or hidden thanks to specific accessories.




Insert the GAP4 fastener into the groove cut so that the clips' central tab adheres to the groove in the board.




Secure the screws in the two available holes.



Position the next board by inserting it into the GAP4 fastener so that the two tabs adhere to the groove in the board.



Using the CRAB MINI clamp, tighten the two boards until the gap between them is 0.16 - 0.20 inch depending on aesthetic requirements (see product page 424).



Repeat the operations for the remaining boards.
Last board: repeat step 01.